

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT - " for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

ENERGEN RESOURCES CORPORATION

3. Address and Telephone No.

2198 Bloomfield Highway, Farmington, NM 87401

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1700' FSL, 1800' FWL, Sec. 33, T26N, R3W, N.M.P.M.

RECEIVED
APR 21 1999

OIL CON. DIV.
DIST. 3

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

Jicarilla Contract 117

6. If Indian, Allottee or Tribe Name

Jicarilla Apache

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Jicarilla 117E 9

9. API Well No.

30-039-21197

10. Field and Pool, or exploratory Area

Blanco Mesaverde

11. County or Parish, State

Rio Arriba NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☒ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

2/15/99 MIRU. Attempted to release packer. Packer stuck. Ran freepoint and cut off tubing at 6052'. TOH.
2/16/99 TIH and clean out to top of fish with air. Latch onto fish with overshot. Jar packer loose and TOH.
2/17/99 TIH. Dropped tubing. TIH with spear and catch fish. TOH.
2/18/99 TIH with RBP & packer. Set RBP at 6095'. Test RBP-OK. Pull up hole to 5490'. Test casing to 1000 psi-OK. Squeeze cement cliff house perfs with 175 sks .4% veraset followed by 200 sks Class B w/ 3# gilsonite, 0.3% halad-344, 0.2% CBL and 2% CaCl2. (463 cu. ft.). WOC.
2/19/99 Try to release packer. Broke safety. TOH. Left BP setting tool in hole.
2/20/99 TIH with spear. Jar on fish. Jar loose. TOH.
2/21/99 TIH with bit. Tag cement at 5590'. Drill cement.
2/23/99 Drill cement to 6035'. Circ. hole clean. Test casing to 500# - OK. TOH. TIH and retrieve RBP. TOH.
2/24/99 TIH and clean out to 6400' with air mist.
2/25/99 Ran 199 joints 2 3/8", 4.7#, J-55 tubing set at 6283'. Seating nipple at 6251'.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title Production Assistant

Date 3/10/99

(This space for Federal or State office use)

Approved by [Signature]

Title Lands and Mineral Resources

Date APR 20 1999

Conditions of approval, if any: