FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No. SF 078056

6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or reentry to a different reservoir,

UNITED STATES

DEPARTMENT OF THE INTÉRIOR

BUREAU OF LAND MANAGEMENT

7, If Unit or CA. Agreement Designation

Use "APPLICATION	FOR PERMIT" for such proposals	- Songhamon
SUBMIT IN TRIPLICATE		Central Bisti Unit
1. Type of Well Oil Well Gas	Well X Other Water Injection Wel	8. Well Name and No. Central Bisti Unit #WI-13
2. Name of Operator		9. API Well No.
Central Resources, Inc. for Giant Exploration & Production Company		30-045-055090
3. Address and Telephone No.		10. Field and Pool, or Exploratory Area
P.O. Box 1213, Bloomfield, New Mexico 87413 (505)632-3476		Bisti Lower Gallup
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish, State
660' FNL, 660' FEL, Sec. 8, T25N, R12W		San Juan, New Mexico
12. CHECK APPROPRIATE BOX(s)	TO INDICATE NATURE OF NOTICE, REPOR	T, OR OTHER DATA
TYPE OF SUBMISSION TYPE OF ACTION		ION
<u></u>	X Abandonment	Change of Plans
Notice of Intent	Recompletion	New Construction
<u></u>	Plugging Back	Non-Routine Fracturing
Subsequent Report	Casing Repair	Water Shut-Off
	Altering Casing	Conversion to Injection
X Final Abandonment Notice	Other	Dispose Water
		(Note: Report results of multiple completion on Well
12 Danilla Dan		Completion or Recompletion Report and Log form.)
directionally drilled give subsurface locate	ons (Clearly state all pertinent dates, including estimated	date of starting any proposed work. If well is

January 9-10th.

- A. Set a CIBP at 4692' and spot cement on top to 4479' using 30 sacks cement.
- B. Bring top of Gartup plug from 1915' to 1867 inside outside 5 1/2" casing using 47 sacks cement, didn't hold
- C. Second attempt, bring top of Gaffup plug to 1759' inside outside 5 1/2" casing using 47 sacks cement.
- D. Set Pictured Cliffs plug from 1175 to 1075' inside and outside 5 1/2" casing using 17 sacks cement.
- E. Place the Fruitland Plug from 850' to 810' inside and outside 5 1/2" casing using 47 sacks cement.
 F. Place the surface casing shoe plug at 400' inside and outside 5 1/2" casing using 47 sacks cement.
- G. Place the surface plug at 175' to surface inside and outside the 5 1/2" casing using 150 sack cement to cover the Ojo Alamo interval.
- H. Cut well head and install dry hole marker. Clear and remediate location.

14. Thereby certify that the foregoing is true and	correct		=
Signed Total	Title Production Technician	Date 01/15/2001	
Patty Shelton			_
(This space for Federal or State office use)			=
Approved by	Title	Date	
Conditions of approval, if any:			_
		TOR RECOR	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any manner within its jurisdiction.