

WORKOVER

1. Set 2" tubing choke @ 5438' and 1 1/4" choke at 3245'.
2. Move in rig. Remove tubinghead and set Blowout preventor.
3. Pull 1 1/4" tubing and 2" tubing with packer seals.
4. Set wire line Baker Model "B" production packer @ 3350'.
5. Run 2" tubing.
6. Run 1 1/4" tubing.
7. Install tubinghead and kick off well.
8. Cleaned location.

STATE OF NEW MEXICO	
OIL COMMISSION	
ADVISORY OFFICE	
NUMBER OF COPIES AT HAND	
DISTRICT	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
TRANSPORTER	
OIL	
GAS	
PRODUCTION OFFICE	
OPERATOR	