

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

14-20-0603-8104

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Navajo

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Navajo Tribe "A1"

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Tocito Dome, Pennsylvanian

11. SEC., T., R., M., OR BEE. AND
SURVEY OR AREA

"D"

2826N-18W, NMDM

12. COUNTY OR PARISH

San Juan

13. STATE
New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Texaco Inc. Prod. Dept. Rocky Mountains U. S.

3. ADDRESS OF OPERATOR

P. O. Box 2100, Denver, Colorado 80201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1930' PSL and 2130' FUL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5732' KB

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☒
☐

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐
☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

We propose to P&A this well because it is uneconomical to produce,
-0- BOPD and -0- BWPD according to test data as of 8-20-70. At present
it is shut-in oil for lack of fluid. Well studies indicate that it is
too tight to use as a W.I. well.

ABANDONMENT PROCEDURE:

1. Run tubing open ended and fill hole with mud.
2. Spot 50 sack plug across perfs 6313-6316. Raise tubing and braidenhead squeeze.
3. Perforate 4 holes at 3900.
4. Set retainer at 3650 and squeeze 3700 to 3900 with 127 sacks of cement leaving top of cement at 3700 in casing. *
5. Perforate 4 holes at 2250.
6. Run tubing and spot 115 sacks of cement. Raise tubing and head squeeze leaving top of cement at 2050 in casing.
7. Remove wellhead and set marker in 10 such surface plug.
8. Cleanup location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

District Superintendent

November 22, 1972

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

USGS (3) OGCC CGR IHB

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any local special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.