



(SUBMIT IN TRIPLICATE)

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Land Office **Santa Fe**
Lease No. **MM 016009**
Unit **W. P. Saunders**

SUNDRY NOTICES AND REPORTS ON WELLS

NOTICE OF INTENTION TO DRILL.....	SUBSEQUENT REPORT OF WATER SHUT-OFF.....
NOTICE OF INTENTION TO CHANGE PLANS.....	SUBSEQUENT REPORT OF SHOOTING OR ACIDIZING.....
NOTICE OF INTENTION TO TEST WATER SHUT-OFF.....	SUBSEQUENT REPORT OF ALTERING CASING.....
NOTICE OF INTENTION TO RE-DRILL OR REPAIR WELL.....	SUBSEQUENT REPORT OF RE-DRILLING OR REPAIR.....
NOTICE OF INTENTION TO SHOOT OR ACIDIZE.....	SUBSEQUENT REPORT OF ABANDONMENT.....
NOTICE OF INTENTION TO PULL OR ALTER CASING.....	SUPPLEMENTARY WELL HISTORY.....
NOTICE OF INTENTION TO ABANDON WELL.....	
Plug and Abandon Well	XX

(INDICATE ABOVE BY CHECK MARK NATURE OF REPORT, NOTICE, OR OTHER DATA)

Hobbs, New Mexico - October 17, 19 63

W. P. Saunders
Well No. **1** is located **660** ft. from **S** line and **1980** ft. from **E** line of sec. **11**

SW/4 SE/4 Sec. 11

26-N

11-W

N.M.P.M.

Dakota Wildcat & Gallup

San Juan

New Mexico

The elevation of the derrick floor above sea level is **6484** ft.

DETAILS OF WORK

(State names of and expected depths to objective sands; show sizes, weights, and lengths of proposed casings; indicate mudding jobs, cementing points, and all other important proposed work)

The oil zone (Gallup) of this well is depleted with the well producing 100% water. The gas zone (Dakota) of this well produced water only on a test and was shut off. There are no other commercial zones of oil or gas in this well. We plan to plug and abandon this well in the following manner:

1. Move in and rig up pulling unit.
2. Pull rods and tubing from Gallup Zone.
3. Pull tubing from the Dakota Zone.
4. Mill over and pull Baker Model "D" Production Packer at 6416'.
5. Drill out Baker Bridge Plug at 6504'.
6. Clean well out to PSTB 6449'.
7. Spot 50 sack cement plugs at the following depths:

6445-6537' - Dakota Zone

5584-5746' - Gallup Zone

(Continued on back of sheet)

I understand that this plan of work must receive approval in writing by the Geological Survey before operations may be commenced

Company **Skelly Oil Company**

Address **Box 730**

Hobbs, New Mexico

By _____

Title **Dist. Supt.**



9. Rig down and move out pulling unit.
10. Move in and rig up pipe pulling machine.
11. Run knee point indicator and cut 7" OD casing.
12. Pull 7" OD casing.
13. Move in and rig up pulling unit.
14. Spot 75 sack (150') cement plug in and cut off OD casing out off point.
15. Spot 50 sack cement plugs at the following depths:
 2725-2825' - CLIFF HOUSE
 1850-1950' - PICTURE CLIFF
 900-1000' - OJO ALMO
16. 10 sack plug at surface in 10-3/4" OD casing with 4" steel marker.
17. All intervals not cemented will be filled with heavy mud laden fluid.