## UNITED STATES

DEPARTMENT OF THE INTERIOR	<b>▲F</b> 079319
GEOLOGICAL SURVEY	. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS	7. UNIT AGREEMENT NAME
(Do not use this form for proposals to drill or to deepen or plug back to a different	
reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME
1. oil gas sa	Schwerdtfeger A
1. oil gas 🖾 other	O WELL NO
2. NAME OF OPERATOR	#6 #6 # #6 # # # # # # # # # # # # # #
El Paso Natural Gas Company	10. FIELD OR WILDCAT NAME
3. ADDRESS OF OPERATOR	South Blanco P.C.
	11. SEC., T., R., M., OR BLK. AND SURVEY OR
P.O. Box 990 Farmington, New Mexico	AREA
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	
below.)	Section 8, T-27-N, R-8-W
AT SURFACE: 850'S of N. line & 930' E of W. AT TOP PROD. INTERVAL:	12. COUNTY OR PARISH 13. STATE
AT TOTAL DEPTH: line of Sec. 8	San Juan New Mexico
	14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,	
REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD)
	6124' DF
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	
SHOOT OR ACIDIZE	
REPAIR WELL	(NOTE: Report results of multiple completion or zone
PULL OR ALTER CASING	change on Form 9–330.)
MULTIPLE COMPLETE	
	DELONGTON ( ) 유통통한 ( ) 1 ( ) 영화공항 ( ) # (
ABANDON*     ABANDON   ABA	하다 뭐 뭐 그는 사람들이 아니는 아름이 없는 것이다.
(other)	
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*	
Procedure to plug and abandon is as follows:	
<u> </u>	
1) MOL and RU.	■ 2000年2月2日 (全)2000年2月2日 (全)2000年2月 (
2) Pull 1" tubing.	물문의 중심 수축되면 하다
3) Run 2" working string to 2280'.	
4) Spot 50 sk plug to cover open hole (2226	
casing to above Pictured Cliffs formation	
5) Pull 28 joints and flush w/80 bbls water	• <u>-                                   </u>
6) Spot a 30 sk plug to cover the Ojo Alamo	Formation (1417' to 1317', in 7"
casing). Pull 4 joints and flush w/55 b	bls. water.
7) Perforate at 182' with 4 shots.	불립하다 보고 중립하고
8) Spot a 75 sk plug (185' to surface). In	stall dry hole marker.
Work will start sometime in the summer o	f 82. ਬੁੱਟਰੂ - ਮੁੱਖ ਜ਼ਿਲਾਉ
*See attached modifications.	2000
Subsurface Safety Valve: Manu. and Type	Set @ Ft.
18. I hereby certify that the foregoing is true and correct	
Production	
SIGNED LE Engineer	DATE March 18, 1982
The Control of State off (This space for Federal or State off	fice use)
MAR 24 1982	그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그
APPROVED BYTITLE	
CONDITIONS OF APPROVAL JAMES F. SIMS	ការប្រជាជា ការប្រជាជា ស្រាស់ ស្រាស ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស់ ស្រាស ស ស ស្រាស ស ស ស្រាស ស ស ស ស ស ស ស ស ស ស ស ស ស ស ស ស ស ស
I STATESTATE CNICINILLED	
AS AMENDED DISTRICT ENGINEER	The solution of the solution o
	29E2 5 292

## U. S. GEOLOGICAL SURVEY Drawer 600 Farmington, New Mexico 87499-00600

Attachment to Notice of Intention to Abandon

Re: Permanent Abandonment

Well: 6 Schwerdtfeger A

## CONDITIONS OF APPROVAL

 Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."

- 2. The Farmington office (telephone (505) 325-4572) is to be notified in sufficient time for a representative to witness all plugging operations.
- 3. Blowout prevention equipment is required.
- 4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Bureau of Land Management for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
- 5. The following modifications to your plugging program are to be made (when applicable):
  - a) Spot cement plug inside casing from 1835 to 1735 to cover top of Fruitland.
  - b) Perforate 7" casing at 182'.

Office Hours: 7:30 A.M. to 4:15 P.M.