

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER		5. LEASE DESIGNATION AND SERIAL NO. SP-078935	
2. NAME OF OPERATOR Beta Development Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR 125 Petroleum Plaza, Farmington, New Mexico 87401		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1850/N 1850/E		8. FARM OR LEASE NAME Thompson Federal	
14. PERMIT NO.		9. WELL NO. 2	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5909' GR		10. FIELD AND POOL, OR WILDCAT Basin Dakota	
16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 10-27N-12W NMFH	
NOTICE OF INTENTION TO: TEST WATER SHUT-OFF ☐ FRACTURE TREAT ☐ SHOOT OR ACIDIZE ☐ REPAIR WELL ☐ (Other) ☐		SUBSEQUENT REPORT OF: REPAIRING WELL ☐ ALTERING CASING ☐ ABANDONMENT* ☒	
PULL OR ALTER CASING ☐ MULTIPLE COMPLETE ☐ ABANDON* ☐ CHANGE PLANS ☐		12. COUNTY OR PARISH San Juan	
		13. STATE New Mexico	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

- 12-31-74 Rigged up work over unit for P & A work tubing loose on bottom, pull 1½" tubing out of hole, lay jts. # 111, 112 & 113 down (holes) go in hole with tubing (replaced 3 jts.) string into nodal "D" production packer, pump 50 sacks cement down tubing displace with 12 bbl's water, pick tubing up to 5480' base of Gallup, pump in 15 sacks cement, displace with 10 bbl's water, pick tubing up to 4280'.
- 1-1-75 Shut down.
- 1-2-75 Pump 15 sacks cement @ 4280' (base of Point Lockout) displace with 8½ bbl's water, pick tubing up set 15 sacks cement @ 1827' (2 stage cellar) lay tubing down, shot casing off 519' pump 25 sacks cement down 4½" casing, lay casing down, pump 25 sacks 195' at base of 10 3/4" casing, put 10 sacks cement in top of surface, no dry hole marker installed (U.S.G.S.).

18. I hereby certify that the foregoing is true and correct

SIGNED D. E. Carter TITLE Superintendent DATE 3-17-75

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.