Form 9-331 (May 1963)

14. PERMIT NO.

## UNITED STATES DEPARTMENT OF THE INTERIOR (Grher Instructions of verse side)

SUBMIT IN TRIPLICATE.

Form approved, Budget Bureau No. 42-R1424. 5. LEAGE DESIGNATION AND SERIAL NO.

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

Sf - 077085 6. IF INDIAN, ALLOTTER OR TRIBE NAME

	GEOL	OGICAL	. SURVEY		····	
SUNDRY	NOTICES	AND	<b>REPORTS</b>	ON	WELLS	

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT" for such proposals.)	
1.	7. UNIT AGREEMENT NAME
OIL GAS WELL X OTHER	8. FARM OR LEASE NAME
Z. NAME OF OPERATOR TENNECO OIL COMPANY	Omler
3. ADDRESS OF OPERATOR	9. WELL NO.
Suite 1200 Lincoln Tower Building, Denver, Colorado 80203  4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*	10. FIELD AND POOL, OR WILDCAT
See also space 17 below.)	Fulcher Kutz P. C.
990 FNL and 990 FEL	11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA Sec. 26, T-28-N, R-10-1

5770 DF Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data 16.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

NOTICE OF INTENTION TO:			SUBSEQUENT REPORT OF:			
NOT TEST WATER SHUT-OFF FRACTURE TREAT	ICE OF IN	PULL OR ALTER CASING MULTIPLE COMPLETE		WATER SHUT-OFF FRACTURE TREATMENT	REPAIRING WELL ALTERING CASING	
SHOOT OR ACIDIZE		ABANDON*		SHOOTING OR ACIDIZING (Other)	ABANDONMENT*	
repair well (Other) Repair (	Ll easing	change plans	X	(Note: Report results of mul Completion or Recompletion R	ltiple completion on Well leport and Log form.)	_

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Move in service unit, Kill well w/treated water, Rig up BOP, Pull 1" tubing, Run approx. 1830' of 3-1/2" 7.7# J-55, NEUE T & C Tubing w/packer shoe. Set Packer shoe at 1830', cement with sufficient volume to circulate and displace an estimated 150 sacks through hole in 5-1/2" casing, W.O.C. 8 hrs., clean out to TD, Re-run tubing, swab if necessary, Test well.



18. I hereby certify that the foregoing is true and correct SIGNED	TITLE Sr. Production Clerk	DATE 11-12-70
(This space for Federal or State office use)		
APPROVED BY	TITLE	DATE