

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well gas ☐ well other ☐  
2. NAME OF OPERATOR  
DUGAN PRODUCTION CORP.  
3. ADDRESS OF OPERATOR  
P O Box 208, Farmington, NM 87499  
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 990' FSL - 990' FEL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
CHANGE ZONES ☐  
ABANDON\* ☒  
(other)

SUBSEQUENT REPORT

RECEIVED  
DEC 08 1982

U. S. GEOLOGICAL SURVEY  
FARMINGTON, N. M.

5. LEASE  
SF 077978-A  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Douthitt

9. WELL NO.

1

10. FIELD OR WILDCAT NAME

Undesignated

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec 33 T28N R13W

12. COUNTY OR PARISH 13. STATE

San Juan NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)

5974 D.F.

TE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plan to plug and abandon well as follows:

- Set Cement return 5338'
1. Squeeze Gallup perms 5388-5548' with 25 sx cement and leave cement in 5 1/2" casing from 5548' to 5288' (35 cu.ft.).
  2. Spot 100' cement plug across top of Cliff House Formation 2388-2288'.
  3. Find casing free point and shoot off casing.
  4. Spot 100' plug at casing stub, 50' inside and 50' above stub.
  5. Spot 10 sx cement plug at surface with dry hole marker.
  6. Clean and restore location per surface management agency's guidelines.

spot plug approx 3800'  
if casing cut off below PC at 1950 Spot plug if not perforate & squeeze  
Spot plug across Fruitland @ 1275' or perforate & squeeze if necessary.  
Spot plug across surface casing line at 200'

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Jim L. Jacobs TITLE Geologist DATE 12-6-82

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL IF ANY

AS AMENDED

DEC 08 1982  
James F. Sims  
DISTRICT ENGINEER

NMOCC