

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Marathon Oil Company

3. Address and Telephone No.

P.O. Box 2409, Hobbs, NM 88240

(505) 393-7106

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit Letter G, 2125' FNL & 1560' FEL
Section 22, T-28-N, R-11-W

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 020499

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Ohio Govt. Sec. 22 1

9. API Well No.

30-045-28343

10. Field and Pool, or exploratory Area

Basin Fruitland Coal

11. County or Parish, State

San Juan County NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other

Reactivation.

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Marathon Oil Company is proposing the reactivation of the Ohio Government 22 Well No. 1. An AFE has been prepared and will be forwarded to working interest owners. Listed below is a brief procedure to reactivate the well.

1. MIRU PU. Install BOP equipment.
2. PU 2 3/8" tubing and RIH open ended to 1500'.
3. RU swab and swab fluid level to 1300'. POOH with tubing.
4. RIH with sand line drill and knock out CIBP at 1500'.
5. ND sand line drill. RIH with 2 3/8" tubing with seating nipple to 1550'.
6. ND BOPE and NU wellhead.
7. RU swab and swab well in.

This work will commence upon approval of the AFE by working interest owners and the 3160-5.

14. I hereby certify that the foregoing is true and correct

Signed

Title Advanced Production Engineer

Date 2/26/97

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

* See Instruction on Reverse Side