- 10 sxs. cement (130') plug from 450' to 320'
- Place 10 sxs. cement (37') plug in top of surface pipe.
- Cut off pipe at bottom of cellar, place one sack cement on top of pipe and install regulation marker.
- Clean up and level location to as near original contour as practicable.

AMOCO PRODUCTION COMPANY	A	
18. I hereby certify that the foregolar risue and correct SIGNED		Sent DATE 7-13-72
(This space for Federal or State office use)		
APPROVED BYCONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE