UNITED STATES

DEPARTMENT OF THE INTERIOR

	Sundry Noti	ces and Reports on Wells		
			5.	Lease Number SF-047017-B If Indian, All. or
Ty	pe of Well	्राप्त । - रहे	•	Tribe Name
	GAS			IIIDe Name
			£ 7.	Unit Agreement Nam
Na.	me of Operator		$g_{\sigma} > -\frac{1}{2}$	
		S MAR		
F	RURLINGTON RESOURCES OIL	& GAS COMPANY		
	011	is to	V 016.	Well Name & Number
Ad	dress & Phone No. of Operat	tor	13/2	Delo #3
P	O Box 4289, Farmington, NM	ارح 87499 (505) 326-9°	202 FL 19.	API Well No.
			10	30-045-20929 Field and Pool
. Lo	cation of Well, Footage, So	C., T, K, M	10.	Fulcher Kutz PC
79	0'FNL, 1755'FWL, Sec.25, T	-20-N, K-II-W, MMFM	11.	
				San Juan Co, NM
	Subsequent Report _X_ Final Abandonment	Recompletion Plugging Back Casing Repair Altering Casing Other -	_ New Construc _ Non-Routine _ Water Shut o _ Conversion t	Fracturing ff
				
3.	Describe Proposed or Comp	leted Operations		
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside o BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2	r/2% calcium ch @ 702'. Plug #	nloride, inside 3: pump 23 sx
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside o BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40	r/2% calcium ch @ 702'. Plug #	nloride, inside 3: pump 23 sx
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM. on location.)	sg @ 1711-1363 7/2% calcium ch @ 702'. Plug ‡ 96'. TOOH. WOC.	nloride, inside 3: pump 23 sx SD for weekend.
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat (Jimmy Morris, 2-14-00 Plug #4: pump 25	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w	r/2% calcium ch @ 702'. Plug # 06'. TOOH. WOC.	aloride, inside 3: pump 23 sx SD for weekend.
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat (Jimmy Morris, 2-14-00 Plug #4: pump 25	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w . WOC. ND BOP. Cut off w	r/2% calcium ch @ 702'. Plug # 06'. TOOH. WOC. 0/2% calcium ch	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w neat cmt. RD. Rig relea	r/2% calcium ch @ 702'. Plug # 06'. TOOH. WOC. 0/2% calcium ch TH. Install dry ased.(Jimmy Mon	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w . WOC. ND BOP. Cut off w	r/2% calcium ch @ 702'. Plug # 06'. TOOH. WOC. 0/2% calcium ch TH. Install dry ased.(Jimmy Mon	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w neat cmt. RD. Rig relea	r/2% calcium ch @ 702'. Plug # 06'. TOOH. WOC. 0/2% calcium ch TH. Install dry ased.(Jimmy Mon	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl
	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat (Jimmy Morris, 2-14-00 Plug #4: pump 25 cmt to surface 8 sx Class "B" Well plugged a	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w neat cmt. RD. Rig releated	r/2% calcium ch @ 702'. Plug # 16'. TOOH. WOC 0/2% calcium ch UH. Install dry	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl
3.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w neat cmt. RD. Rig releated	r/2% calcium ch @ 702'. Plug # 16'. TOOH. WOC 0/2% calcium ch UH. Install dry	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl
4.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat (Jimmy Morris, 2-14-00 Plug #4: pump 25 cmt to surface 8 sx Class "B" Well plugged a	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w neat cmt. RD. Rig releated	r/2% calcium che 702'. Plug # 16'. TOOH. WOC. r/2% calcium che 174. Install dry 185ed. (Jimmy Monescorrect.	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl hole marker w/ cris, BLM, on locati
4.	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat (Jimmy Morris, 2-14-00 Plug #4: pump 25 cmt to surface 8 sx Class "B" Well plugged a	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w e. WOC. ND BOP. Rig releated abandoned on 2-14-00.	r/2% calcium che 702'. Plug # 16'. TOOH. WOC. r/2% calcium che 174. Install dry 185ed. (Jimmy Monescorrect.	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl hole marker w/ cris, BLM, on locati
4. ign	2-9-00 MIRU. SDON. 2-10-00 ND WH. NU BOP. T pump 27 sx Cla (Jimmy Morris, 2-11-00 Plug #2: pump 24 csg @ 852-542' Class "B neat (Jimmy Morris, 2-14-00 Plug #4: pump 25 cmt to surface 8 sx Class "B" Well plugged a	OOH w/1 ½" tbg & pkr. TI ss "B" neat cmt inside of BLM, on location.) sx Class "B" neat cmt w . WOC. TIH, tag plug #2 cmt, inside csg @ 702-40 BLM, on location.) sx Class "B" neat cmt w e. WOC. ND BOP. Cut off w e. WOC. ND BOP. Rig releated abandoned on 2-14-00.	r/2% calcium che 702'. Plug # 16'. TOOH. WOC. r/2% calcium che 174. Install dry 185ed. (Jimmy Monescorrect.	aloride, inside 3: pump 23 sx SD for weekend. aloride. Circ 1 bbl hole marker w/ cris, BLM, on locati