## (SUBMIT IN TRIPLICATE)

## UNITED STATES **DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY**

Budget Bureau No. 42-R358.4. Approval expires 12-31-60.

Land Office Santa Fe

Loase No. 076337

Unit W. D. Heath As

NOTICE OF INTENTION TO CHANGE	1 1	SUBSEQUENT REPORT OF RE-DRILLING OR REPAIR.			
NOTICE OF INTENTION TO TEST WAT					
NOTICE OF INTENTION TO RE-DRILL	<b>₩</b>				
NOTICE OF INTENTION TO SHOOT O					
NOTICE OF INTENTION TO PULL OR	ALTER CASING	SUPPLEMEN			
NOTICE OF INTENTION TO ABANDON		1 11			
		<u>  </u>			
(INDIC	ATE ABOVE BY CHECK MAR	K NATURE OF REPO	RT, NOTICE, OR OTHER DATA)		
		*	May 25,	, 19	
Vell No2 is loca	and some fe from	_ ∫N] line ar	d esa ft from [E]	ine of sec 17	
	ited 1023 it. iroi	in inte at		inc or sec.	
of Section 17	(Twp.)	(Range)	N.M.P.M. (Meridian)		
(¼ Sec. and Sec. No.)	San Jam	(Range)	How Harriso		
100-7000 VOFUS (Field)		or Subdivision)	(State or Te	erritory)	
DECORRER TO MOLECULE		7 66 74774			
	p workover rig.	•	whipstock hole, if	necessary.	
. Howe in and rig up. Cleanout hole with . Run 5" liner to to	p workover rig. h gas to total otal depth and	depth, or t	whipstock hole, if		
. Here in and rig up. Cleanout hole with Run 5" liner to to Drill out coment	p workover rig. h gas to total otal depth and and perforate s	depth, or t	whipstock hole, if		
. Howe in and rig up . Cleanout hole with . Rum 5" liner to to	p workover rig. h gas to total otal depth and and perforate s	depth, or t	whipstock hole, if	20 .57	
. Here in and rig up . Cleanout hole with . Run 5" liner to to . Drill out coment	p workover rig. h gas to total otal depth and and perforate s	depth, or t	whipstock hole, if	LLIVED ST	
. Here in and rig up . Cleanout hole with . Run 5" liner to to . Drill out coment	p workover rig. h gas to total otal depth and and perforate s nd-water frac.	depth, or t cement.	nes.  Ri Oil	LLIVED 57 CON. COM.	
. Heve in and rig up. Cleanout hole with . Rum 5" liner to to . Drill out coment . Stimulate with said . Stimulate with said . I understand that this plan of wo	p workover rig. h gas to total otal depth and and perforate s nd-water frac. rk must receive approval	depth, or to coment.  coment.  colocted set	nes.  Ri Oil	CON. COM.	
. Howe in and rig up. Cleanout hole with . Run 5" liner to to . Drill out coment :	p workover rig. h gas to total otal depth and and perforate s nd-water frac. rk must receive approval	depth, or to coment.  coment.  colocted set	nes.  Ri Oil	CON. COM.	
Nove in and rig up. Cleanout hole with . Run 5" liner to to . Drill out coment a . Stimulate with said . I understand that this plan of wo	p workover rig. h gas to total otal depth and and perforate a nd-water frac. ok must receive approval	depth, or to coment.  pelected ser	nes.  Ri Oil	CON. COM.	
Row in and rig up Cleanout hole with Run 5" liner to to Drill cut cement Stimulate with said	p workover rig. h gas to total otal depth and and perforate a nd-water frac. ok must receive approval	depth, or to coment.  pelected ser	nes.  Ri Oil	CON. COM.	