

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-1203-4

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator AMOCO PRODUCTION COMPANY	8. Farm or Lease Name State Gas Com "I"
3. Address of Operator 501 Airport Drive Farmington, NM 87401	9. Well No. 1
4. Location of Well UNIT LETTER <u>K</u> . <u>1825</u> FEET FROM THE <u>South</u> LINE AND <u>1560</u> FEET FROM THE <u>West</u> LINE, SECTION <u>2</u> TOWNSHIP <u>29N</u> RANGE <u>9W</u> NMPM.	10. Field and Pool, or Wildcat Blanco Mesaverde
15. Elevation (Show whether DF, RT, GR, etc.) 6408' GL	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Amoco Production Company proposes to repair a suspected casing leak as follows:

- 1) Isolate casing leaks by pressure testing with a bridge plug and packer.
- 2) Squeeze casing leaks with cement.
- 3) Run a 5", 14.87#, J-55 casing liner and tie into the existing 5" liner. Cmt. above liner with 575 sx cement.
- 4) Drill out cement and bridge plug and clean well up.
- 5) Land Tubing and reconnect to sales line.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>SVORODA</u>	TITLE <u>District Adm. Supervisor</u>	DATE <u>4/17/79</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DIST. 3</u>	DATE <u>APR 19 1979</u>

CONDITIONS OF APPROVAL, IF ANY: