

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☒ well other ☐

2. NAME OF OPERATOR
Tenneco Oil Company

3. ADDRESS OF OPERATOR
720 So. Colorado Blvd., Denver, Co. 80222

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1670' FNL & 1070' FEL, Unit H
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>		<input type="checkbox"/>
(other)			

5. LEASE
SF 080246

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Florance

9. WELL NO.
57

10. FIELD OR WILDCAT NAME
Blanco Pictured Cliffs

11. SEC., T., R., M. OR BLK. AND SURVEY OR AREA
Sec. 22, T-29-N, R-9-W

12. COUNTY OR PARISH
San Juan

13. STATE
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
5793' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The casing for this well is collapsed.

We propose to plug and abandon via the following procedure:

- 1) MIRIPU
- 2) RIH w/1 1/4" I J tbg to 2334'
- 3) Mix and pump 15 bbls 50/50 poz mix slurry w/6% Bentonite gel down tbg
- 4) Close BOP & pump cement dn tbg to 500 psi squeeze pressure (approx 13.5 bbl/50 Sx squeeze) 125 Sx dry cement required (assuming 50 Sx needed for squeeze)
- 5) Release pressure & pump 4.5 bbls water dn tbg for displacement
- 6) POOH w/tbg-laying down
- 7) Cut off wellhead 1' below grade & install P&A marker. Clean & restore location in accordance with USGS requirements.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Curly Statton TITLE Admin. Supervisor DATE 4/12/79

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

