

submitted in lieu of Form 3160-5

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well  
GAS

5. Lease Number  
SF-Q80032-A

6. If Indian, All. or  
Tribe Name

2. Name of Operator

**BURLINGTON  
RESOURCES**

OIL & GAS COMPANY

Unit Agreement Name

3. Address & Phone No. of Operator

PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M

925' FSL, 800' FEL, Sec.13, T-29-N, R-9-W, NMPM

RECEIVED  
JUL - 6 1999  
OIL CON. DIV.  
DIST. 3

Well Name & Number  
Feuille #1A

9. API Well No.  
30-045-21717

10. Field and Pool  
Blanco Mesaverde

11. County and State  
San Juan County, NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

|                                                      |                                                           |                                                  |
|------------------------------------------------------|-----------------------------------------------------------|--------------------------------------------------|
| <input checked="" type="checkbox"/> Notice of Intent | <input type="checkbox"/> Abandonment                      | <input type="checkbox"/> Change of Plans         |
| <input type="checkbox"/> Subsequent Report           | <input type="checkbox"/> Recompletion                     | <input type="checkbox"/> New Construction        |
| <input type="checkbox"/> Final Abandonment           | <input type="checkbox"/> Plugging Back                    | <input type="checkbox"/> Non-Routine Fracturing  |
|                                                      | <input type="checkbox"/> Casing Repair                    | <input type="checkbox"/> Water Shut off          |
|                                                      | <input type="checkbox"/> Altering Casing                  | <input type="checkbox"/> Conversion to Injection |
|                                                      | <input checked="" type="checkbox"/> Other - Tubing Repair |                                                  |

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

14. I hereby certify that the foregoing is true and correct.

Signed [Signature] Title Regulatory Administrator Date 6/14/1999  
trc

(This space for Federal or State Office use)

APPROVED BY [Signature] Title Reg. Eng. Date 7-1-99  
CONDITION OF APPROVAL, if any:


Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.


NMOCD

**Feuille #1A**  
**Blanco Mesaverde, DPNO: 4820501**  
**925' FSL, 800' FEL**  
**Unit P, Section 13, T-29-N, R-09-W**  
**Latitude: 36° 43.22478', Longitude: 107° 43.48206'**

**Tubing Repair Procedure**

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.**
2. MOL and RU workover rig. Hold daily safety meetings. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. 2-3/8" tubing is set at 5565'. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBTD should be at +/-5693'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build-up and notify Operations Engineer.
4. If fill is encountered, TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to below perforations, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.** If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations.
5. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom then 1/2 of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.
6. Land tubing at ±5565'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN. RD and MOL. Return well to production.

Recommended:   
Operations Engineer

Approved:  6-2-99  
Drilling Superintendent

Operations Engineer: Mike Haddenham  
BR Office - 326-9577  
Pager - 327-8427  
Home - 326-3102

MDH/amm  
5/25/1999