

Archuleta Gas Com "A" #1

cont.

4. Release pkr. POOH W/pkr. Drill out cmt. Pressure test squeeze to 1000#.
5. Wash sand off RBP. POOH w/RBP. TIH W/ 2 3/8" tubing, land at 6624'.
6. NDBOP. NUWH. Swab tbg. RDMOSU. Return well to production.

Please call Cindy Burton (303)830-5119 if you have any questions.