			/	
NO. OF COPIES RECEIVED 3			Form C-103 Supersedes Old	
DISTRIBUTION	NEW MEXICO OIL CONSERV	VATION COMMISSION	C-102 and C-103 Effective 1-1-65	
SANTA FE	NEW MEXICO OIL CONSERV	VATION COMMISSION		
FILE		ſ	5a. Indicate Type of Lease	
U.S.G.S.		İ	State Fee	
LAND OFFICE			5. State Oil & Gas Lease No.	
OPERATOR			NM 012709	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "MAPPLICATION FOR PERMIT —" (FORM C-101) FOR SUCH PROPOSALS.)				
1. OIL GAS X	OTHER•		7. Unit Agreement Name San Juan 30-6 Unit	
2. Name of Operator			8. Farm or Lease Name	
El Paso Natural Gas Company			San Juan 30-6 Unit	
3. Address of Operator			9. Well No.	
PO Box 990, Farmington, NM 87401			8	
4. Location of Well			10. Field and Pool, or Wildcat	
K 1	750' South	890'	Blanco Mesa Verde	
UNIT LETTER	FEET FROM THE	LINE AND FEET FROM		
West	31 30N	7W		
THE LINE, SECTI	ON TOWNSHIP	RANGENMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)			12. County	
6020'DF			Rio Arriba	
16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data				
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:				
PERFORM REMEDIAL WORK	PLUG AND ABANDON R	EMEDIAL WORK	ALTERING CASING	
TEMPORARILY ABANDON	i `	OMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT	
PULL OR ALTER CASING	CHANGE PLANS C	ASING TEST AND CEMENT JQB		
Repair Well	[* 4]	OTHER		
OTHER				
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.				
It is intended to repair a casing leak in the following manner:				
Set a retrievable bridge plug above the Mesa Verde perforations.				
Locate hole in casing with a packer.				
Run cement retainer set above casing leak and squeeze with cement.				

pertinent dates, including estimated date of starting any proposed			
n the following manner:			
Set a retrievable bridge plug above the Mesa Verde perforations.			
Locate hole in casing with a packer.			
Run cement retainer set above casing leak and squeeze with cement.			
Drill out cement, retrieve bridge plug and return well to production.			
PR 1 6 1976 CON. COM. DIST 3 Lee and belief			
ing Clerk April 15, 1976			
DIST. #3APR 1 6 1976			