

6/3/92

ACD- FRANK CHAVEZ

JOHNNY ROBINSON

320 0545 MOBILE
TODAY ONLY

PROPOSED PLUGGING PROCEDURE - HARTMAN #1 DAKOTA

1. SET CEMENT PLUG @ 50 FT ABOVE MESA VERDE
(MESA VERDE TOP @ 3210 FT)
To 3160
3260
3290

2. SET CEMENT PLUG @ 50 FT ABOVE AND 50 FT.
BELOW PICTURADO CLIFFS 1590
(P.C. TOP @ 1640 FT.) To 1690

3. SET CEMENT PLUG @ 50 FT ABOVE AND 50 FT.
BELOW FRUITLAND 1360
(FRUITLAND TOP @ 1410 FT.) To 1460

5. SET CEMENT PLUG @ 50 FT ABOVE AND 50 FT.
BELOW OJO ALAMO 354
(OJO ALAMO 354 TO 530) To 580
640

COMBINE
4+5

6. SET CEMENT PLUG @ 50 FT BELOW SURFACE 50

PERFORATIONS WILL BE MADE TO PUT CEMENT INSIDE AND
OUTSIDE OF PIPE FOR EACH PLUG
SET CEMENT PLUG IN FARMINGTON

550
TO
650

(Spotted out 3275?)

P-22-29N-11W
API 30-045-07961