

NMOC

**NW CHA CHA UNIT
SAN JUAN COUNTY, NEW MEXICO**

PROCEDURE TO P&A WELL NO. 7

1. Move in & rig up pulling unit
2. Set bridge plug 50' above top perf
3. Spot cement to 50' above Gallup
4. Shoot casing and recover casing
5. Set plug in and out of top of casing, 100' plug w/25 sx cement
6. Set 100' plug w/30 sx cement across Cliffhouse formation
7. Set 100' plug w/30 sx cement across Fruitland/Picture Cliffs formation
8. Set 25 sx cement plug at surface
9. Install dry hole marker