

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒ **XX**

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Southland Royalty Company	8. Farm or Lease Name Beck
3. Address of Operator P.O. Drawer 570, Farmington, New Mexico 87499	9. Well No. 1
4. Location of Well UNIT LETTER <u>G</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>1650</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>29N</u> RANGE <u>12W</u> N.M.P.M.	10. Field and Pool, or Wildcat Fulcher Kutz P.C.
15. Elevation (Show whether DF, RT, GR, etc.) 5892' GR	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	* Revised <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	PLUS AND ABANDON <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUS AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SOUTHLAND ROYALTY COMPANY hereby proposes to plug and abandon the subject well in the following manner:

- 1) Rig up and pull 1" pipe.
- 2) Establish rate down 3-1/2" casing and pump 80 sacks cement with 3% CaCl₂ (94 cu.ft.). Displace to 800'. Shut in and allow to set.
- 3) Shoot squeeze hole at 800'.
- * 4) Pump 95 sacks cement with 3% CaCl₂ (114 cu.ft.) with 50 sacks to be squeezed through squeeze holes at 800' and balance to remain in casing and fill to surface.
- * 5) Cut off casing and dump cement to fill to surface. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Petroleum Engineer DATE NOV 14 1983

APPROVED BY [Signature] TITLE DEPUTY OIL & GAS INSPECTOR, DIST. #1 DATE NOV 15 1983

CONDITIONS OF APPROVAL, IF ANY: