

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-045-13324
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: Gallegos Canyon Unit
8. Well No. 187
9. Pool name or Wildcat Basin Fruitland Coal & Kutz PC, West

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator BP America Production Company	
3. Address of Operator P.O. Box 3092 Houston, Tx 77253	
4. Well Location Unit <u>Letter F</u> <u>2220</u> feet from the <u>North</u> line and <u>1600</u> feet from the <u>West</u> line Section <u>30</u> Township <u>29N</u> Range <u>12W</u> NMPM <u>San Juan</u> , County	
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 5348'	

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPLETION <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: T&A WELLBORE <input checked="" type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

BP America Production Company requests permission to continue the shut-in status of this well that has been SI since March 1998. The well has been reviewed for future potential. It was determined to T&A the wellbore in order to hold for re-entry of the Dakota or potential coal infill. Please see the attached T&A procedure.

For technical questions please call Allen Kutch @281-366-7955.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Cherry Hlava TITLE Regulatory Analyst DATE 02/06/2002  
Type or print name Cherry Hlava Telephone No. 281-366-4081  
(This space for State use)  
APPROVED BY DEPUTY OIL & GAS INSPECTOR, DIST TITLE DEPUTY OIL & GAS INSPECTOR, DIST DATE FEB 11 2002  
Conditions of approval, if any:

## San Juan Basin Well Work Procedure

**Well Name:** GCU 187  
**Version:** #1  
**Date:** 2/4/2002  
**Budget:** DRA  
**Repair Type:** Temporary Abandonment

---

### Objectives:

1. TXA wellbore; hold for re-entry of the Dakota or potential coal infill.

---

### Pertinent Information:

Location:	Sec 30 T29N R12W	Horizon:	Basin Dakota
County:	San Juan	API #:	30-045-13324
State:	New Mexico	Engr:	Allen Kutch
Lease:		Phone:	(281)366-7955

---

---

### Formation Tops: (Estimated formation tops)

Nacimiento:		Menefee:	
Ojo Alamo:		Point Lookout:	
Kirtland Shale:		Mancos Shale:	
Fruitland:		Gallup:	4868
Pictured Cliffs:	1195	Graneros:	
Lewis Shale:		Dakota:	5810
Chacra:		Morrison:	
Cliff House:	2955		

---

### Bradenhead Test Information:

Test Date:	Tubing:	Casing:	BH:	
Time	BH	CSG	INT	CSG
5 min				
10 min				
15 min				

---

Comments:

### **Temporary abandonment procedure**

1. Contact Federal and State agencies prior to starting P&A work (NMOCD Charlie Perrin, 505-334-6178 X16, BLM 505-599-8907).
2. Check location for anchors. Install if necessary. Test anchors.
3. MIRUSU. Check and record tubing, casing and bradenhead pressures.
4. Blow down well and kill well, if necessary, with lease water.
5. ND wellhead. NU BOP's.
6. POOH with 2-3/8" tbg, visually inspecting.
7. TIH with CIBP on tbg. Set CIBP at 5650' to abandon the DK perfs.
8. Load well with inhibited lease water. Test casing to 550 psi for 30 minutes.
9. Land 2-3/8" tbg. ND BOP, NU WH.
10. RDMO SU.

GCU 187 - Proposed T&A Configuration  
San Juan County, NM  
Unit F Section 30 T29N - R12W  
Run 25

2-04-2002  
ATK

KB: 12' above GL

