

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-1135  
Expires September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

AMOCO PRODUCTION COMPANY

3. Address and Telephone No.

P.O. BOX 800, DENVER, COLORADO 80201. ATTN: JOHN HAMPTON RM 1846

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1780' FSL, 1495' FEL, Sec. 6, T30N R8W

5. Lease Designation and Serial No.

NM-09717

6. If Indian, Allottee or Tribe Name

7. If Unit or C.A. Agreement Designation

8. Well Name and No.

Florance

9. API Well No.

#37A

10. Field and Pool, or Exploratory Area

Blanco Mesaverde

11. County or Parish, State

San Juan, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
Abandon cathodic protection well

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

The cathodic protection well associated with the above well will be plugged and abandoned per the attached procedure.

RECEIVED  
JUL 18 1990  
OIL CON. DIV  
DIST. 9

APPROVED

JUL 13 1990  
AREA MANAGER

Please contact Cindy Burton (303)830-5119 if you have any questions.

14. I hereby certify that the foregoing is true and correct

Signed

*J. Hampton*

Title

Sr. Staff Admin. Supr.

Date

6/8/90

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

GROUND BED ABANDONMENT

WELL NAME: FLORANCE 37-A

LOCATION: S6-T30-R8

- 1) Weld 6 " dia. spool with diverter line to pit
- 2) MIRU
- 3) Wash in hole with 1 1/4" work string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to TD ~~ff.~~
- 4) Pump \* sx of neat cement w/ 1/4 lb. sk. Flocele. Pull out work string.
- 5) Top off hole with cement, set flexible pipeline marker as PxA marker.
- 6) RDMO

Ground Bed Specifications

TD \_\_\_\_\_ ft.  
Hole Dia. \_\_\_\_\_ inches.  
Casing Dia. \_\_\_\_\_ inches  
Casing Length \_\_\_\_\_ ft.

} UNKNOWN

$$\text{sacks of cement} = (\text{dia.})^2 \times \text{T.D.} \times .00693$$

WHERE dia. is in inches,  
TD is in feet.

JAB.GRA