UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

	Sundry Notice	es and Report	ts on Wells	2001 FEB	12 PM 3:08
				5.	
. Type of Well				6.	SF-080655 If Indian, All. of Tribe Name
				7.	Unit Agreement Nam
. Name of Operator		-			
BURLING! RESOURCE	- 20				
<i>MESCORE</i>	OIL &	GAS COMPANY		8.	. Well Name & Numbe
. Address & Phone No	of Operato	r	206 0720	0	Hare #22A
PO Box 4289, Farm	ington, NM	87499 (505)	326-9700	9.	. API Well No. 30-045-23454
4. Location of Well, Footage, Sec., T, R, M			10	Field and Pool	
1850'FSL, 900'FEL,	Sec.14, T-2	9-N, R-10-W,	NMPM	13	Aztec PC/Blanco M l. County and State San Juan Co, NM
			0= N0=70B	DELDODE OF	ED DAMA
2. CHECK APPROPRIATE Type of Submission		CATE NATURE T	ype of Act	ion	ER DAIA
X_ Notice of	Intent	Abandonm	ent	_ Change of 1 New Constru	Plans
Subsequent	Report	Recomple Plugging	Back	_ New Constin	e Fracturing
	•	Casing R	Repair	Water Shut	off to Injection
- 1 7 7 .					
Final Abar	ndonment	Aftering _X_ Other -	g Casing commingle	_ 0011701191011	to injection
Describe Propos It is intended	sed or Comple	X Other -	commingle ons well acco		attached procedure.
Describe Propos It is intended	sed or Comple	X Other -	commingle ons well acco		· · · · · · · · · · · · · · · · · · ·
Describe Propos It is intended	to commingle vide surface	X Other - eted Operations the subject stipulations foregoing is Title	true and o	rding to the	attached procedur

Hare 22A

Pictured Cliffs/Mesaverde AIN: 2725801 and 2725802 1850' FSL & 900' FEL Unit I, Sec. 14, T29N, R10W

Latitude / Longitude: 36° 43.43' / 107° 50.87'

Recommended Commingle and Pumping Unit Installation Procedure

Project Summary: The Hare 22A is a dual Pictured Cliffs/Mesaverde well drilled in 1979. The tubing has not been pulled since originally installed. The Pictured Cliffs is producing 30 MCFD and has a cumulative production of 323 MMCF. The Mesaverde is producing 59 MCFD and has a cumulative production of 555 MMCF and 5.0 MSTB. We plan to commingle this well, add production equipment and install a pump jack, pump and rods in order to keep the well unloaded. Estimated uplift is and 20 MCFD for the Pictured Cliffs and 50 MCFD and 4 BOPD for the Mesaverde.

- 1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- 2. MOL and RU workover rig. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with 2% KCl water as necessary. ND wellhead and NU BOP. Test and record operation of BOP rams. Have wellhead and valves serviced at machine shop to convert to a single string wellhead (2-3/8"). Test secondary seal and replace/install as necessary.
- 3. Set a plug with wireline in the SN on the Mesaverde tubing. Pick up 1-1/4" tubing and TOOH laying down the 1-1/4", 2.33#, J-55 Pictured Cliffs tubing (set at 2284').
- 4. Release the seal assembly from the PBR at 2448' with straight pickup (no rotation required). If seal assembly will not come free, then cut 2-3/8" tubing above the PBR and fish with overshot and jars. TOOH with 2-3/8", 4.7#, J-55 tubing (set at 4640'). Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- 5. TIH with 3-7/8" bit and a watermelon mill on 2-3/8" tubing and cleanout to PBTD at +/- 4696'. PU above the perforations and flow the well naturally, making short trips for clean up when necessary. TOOH with tubing. Note: when using air/mist, the minimum mist rate is 12 bph. Try to maintain air rate at 1,400 cfm. A hydrocarbon stable foamer should be utilized since this well makes significant amounts of condensate.
- 6. Rabbit all tubing prior to TIH. TIH with one joint of 2-3/8" 4.7# J-55 tubing with purge valve on bottom, 77" Stanley gas separator, 10' pup joint, 6' pup joint, 1.78" seating nipple, and then remaining 2-3/8" tubing. Replace any bad joints. Land tubing at +/- 4646' or 50' above CO PBTD. Note: If excessive fill is encountered, discuss landing depth with Operator Engineer. ND BOP and NU WH.
- 7. If fill was encountered, contact Operations Engineer to discuss possibility of running a sand screen on the pump. PU and TIH with 2" x 1. 25" x 16' RWAC-Z insert pump from Energy Pump & Supply, and ¾" Norris "D" sucker rods to surface. Install sucker rods with spray metal couplings on bottom half of string. Pressure test to 500#. Test pump action and hang rods on pumping unit. RDMO. During cleanout operations the reservoir may be charged with air. As a result of excess oxygen levels that may be in the reservoir and/or wellbore, contact the Lease Operator to discuss the need for determining oxygen levels prior to returning the well to production. Return well to production.



Production will set pump off control. 8.

Recommended:

Operations Engineer

Approval: Bruce D. Bowe Drilling Superintendent

Contacts:

Operations Engineer

Joe Michetti

Office - 326-9764

Pager - 564-7187

Sundry Required: (YES)/ NO

Lease Operator: Specialist:

Mike Gould

Steve Florez

Cell: 320-2509

Pager: 326-8405

Terry Nelson

Office: 326-8560

Cell: 320-2503 Cell: 320-0029

Pager: 326-8473 Pager: 326-8199

JAM/jms

Foreman:

no stips

