State of New Mexico Submi - Conice Form C-103 Energy, Minerals and Natural Resources Department to Appropriate
District Office Revised 1-1-89 OIL CONSERVATION DIVISION DISTRICT WELL AP NO. P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 09418 Santa Fe, New Mexico 87504-2088 DISTRICT II P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease FEE x STATEL DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410 6. State Oil & Gas Lease No. SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) Riverine 1. Type of Well: MEIT OIL WELL X OTHER 2. Name of Operator Robert L. Bayless Address of Operator 9. Pool name or Wildcat PO Box 168 Farmington, NM 87499 Fulcher Kutz Pictured Cliffs 4. Well Location 1151 South 1995 Unit Letter Feet From The Line and Feet From The Line 11 29N 13N NMPM San Juan Section Township County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 5326 GR Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT **PULL OR ALTER CASING** CASING TEST AND CEMENT JOB OTHER: Spud and set surface casing OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. See attached daily report I hereby certify that the information true and complete to the best of my knowledge and belief. DATE 3-20-96 _ time Engineer TELEPHONE NO. 326 - 3 TYPE OR PRINT NAME FURTHER WEST OF STREET TITLE .

CONDITIONS OF APPROVAL, IF ANY:

Robert L. Bayless

Riverine #1 1151 FSL & 1995 FEL Section 11-T29N-R13W San Juan County, New Mexico

Morning Reports-Drilling

3/6/96

Prepare location for rig.

3/19/96

Move in track hoe. Dig cellar to 22 ft through boulders. Place 20 ft of 10 3/4" conductor pipe in hole and pour 5 yards of concrete. Backfill cellar with rock and gravel. Move rig onto location.

3/20/95

Rig up L&B Speed Drill. Spud well at 10:00 am, 3/19/96. Drill 8 3/4" hole to 130 ft. Run 3 joints (124.85 ft) 7" 23 #/ft J-55 new casing. Set casing at 126 ft, cement with 57 sx Class B with 2 % CaCl. Good returns throughout job, circulate 5 bbls good cement to pit. Plug Down at 6:30 pm. WOC.