Form 3160-5 (June, 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM	APPROVED	
1 01 (14)	~	

Budget Bureau No. 1004-0135

Expires: March 31, 1993

•	Lease	Desig	nation	and	Serial	No.

SUNDRY NOTICES AND REPORTS ON WELLS 14-20-603-2198 Do not use this form for proposals to drill, or to deepen or reentry to ardifferent reservoir. 6. If Indian, Allotte or Tribe Name Use "APPLICATION FOR PERMIT-" for such proposes **OLAVAJO** OCT 2001 7. If Unit or CA, Agreement Designation SUBMIT IN TRIPLICATE 1. Type of Well 8. Well Name and No. Oil Well Gas Well WF NAVAJO 14-1 2. Name of Operator 9. API Well No. Richardson Operating Company 30-045-30485 3. Address and Telephone No. 1700 Lincoln, Suite 1700, Denver, Colorado 80203 (303) 830-8009 10. Field and Pool, or Exploratory Area WEST KUTZ PC 4. Location of Well (Footage, T, R, M, or Survey Description) 1690' FSL & 660' FEL 11. County or Parish, State SEC. 14-29N-14W San Juan County, NM CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF ACTION Change of Plans Abandonment Notice of Intent Recompletion New Construction Non-Routine Fracturing Plugging Back Water Shut-Off Subsequent Report Casing Repair Conversion to Injection Altering Casing Dispose Water Surface Casing/Cementing Final Abandonment Notice Other: see below (Note: Report results of multiple completion on Well

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.

If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markets and zones pertinent to this work.)*

3-06-01 Spud well with 8 3/4" surface hole. Drill to 140 feet. Circulate hole and pooh w/ drill pipe. RIH w/ 3 jt of 7" 20# casing to 138.5 feet. Cemented with 50 SX class B Neat Cement. Circulated 4 bbl cement to surface.

3-07-01 NUBOP and test BOP to 1000#. Drill w/ 6 1/4" bit to 550' and circulate hole clean.

3-08-01 Drill to 1035'. Circulate hole clean. LD drill pipe. RIH w/ 25 jt 4 1/2" j-55 10.5# casing to 1026.31'.

Pump 55 SKS class B + 2% S.M., 60SK class B + 1/4#/SK C.F. Bump plug and test to 1000#.

Circulated 8 bbl cement to surface. Rig down.

* See Instructions on Reverse Side

OB RECOR

1 9 200)