

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name MONTANO
8. Well No. 1
9. Pool name or Wildcat FULCHER-KUTZ-P.C.
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator NORMAN L. GILBREATH
3. Address of Operator Box 208, AZTEC, NEW MEXICO 87410
4. Well Location Unit Letter N : 330 Feet From The SOUTH Line and 1650 Feet From The NORTH Line Section 28 Township 30N Range 12W NMPM SAN JUAN County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRR. KILL WELL WITH H₂O IF NECESSARY.
2. PULL RODS. RELEASE AND PULL PKR AND TBG. INSPECT TBG, IF OK USE FOR WORK STRING.
3. TH WITH TBG, CLEAN OUT TO AT LEAST 50 FT BELOW CSG SHOE AT 1530 FT.
4. SET 200 FT PLUG, 1580-1380. WOC 4 HRS. TAG PLUG #1. IF IN PLACE, GO TO STEP 5. IF NOT, FILL TO 1380 FT.
5. PERF @ 850'. SET 150' PLUG IN AND OUTSIDE CSG UNDER PACKER OR RETAINER, WOC 4 HRS AND TAG.
6. PERF @ 250'. CIRC CMT TO SURF UP BRADENHEAD. LEAVE CSG FULL.
7. SET DRY HOLE MARKER. CLEAN AND LEVEL LOCATION.

RECEIVED

DEC 31 1992

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Norman L. Gilbreath TITLE OPERATOR OIL CON. DIV. 1-92
DATE DIST. 3
TYPE OR PRINT NAME NORMAN L. GILBREATH TELEPHONE NO. 632-8845

(This space for State Use)

Original Signed by CHARLES GHOLSON

DEPUTY OIL & GAS INSPECTOR, DIST. #3

APPROVED BY _____ TITLE _____ DATE 12/31/92

CONDITIONS OF APPROVAL, IF ANY: