

(SUBMIT IN TRIPLICATE)

Land Office Sente Fe

UNITED STATES

Lease No. 078387

DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

4-6 110.	· · · · · · · · · · · · · · · · · · ·	(~ ~ ~	
U		m)1	
			`; L'
SEF			

SUNDRY NOTICES AND REPORTS ON WELLS

	TICES AND REPORTS ON WELLS
TO DE OF INTENTION TO DRILL	
NOTICE OF INTENTION TO CHANGE PLANS	SUBSEQUENT REPORT OF WATER SHUT-OFF
MOTICE OF INTENTION TO TEST WATER SHIPE	SOUSEQUENT REPORT OF SHOOTING OF
TOTAL OF INTENTION TO RE-DRILL OF DEPAIR	DESEQUENT REPORT OF ALTERING CASING
TOTAL OF INTENTION TO SHOOT OF ACIDITE	SOUSEWOEN REPORT OF RE-DRILLING OF
THE OF INTENTION TO PULL OR ALTED CARL	NO SOUDENI REPORT OF ABANDONMENT
I THEN LION TO ARANDON NEWS	TOTAL LAMENTARY WELL HICTORY
Notice of Intention to Work	Total Control of the
(INDICATE AROUS D	tover X
	Y CHECK MARK NATURE OF REPORT, NOTICE, OR OTHER DATA)
	September 26
Vell No. 1-D :- 1-000	
Vell No. 1-D is located 990	ft. from S line and 990 ft. from w line of sec.
SW/4 Sec. of	w line of sec.
(1/2 Sec and Sec av.)	N N N T M
llanco Masa Yorda	p.) (Range) (Meridian)
(Field)	San Jam
	(County or Subdivision)
ne elevation of the derrick floor abov	(Coase of Territory)
· Move in workows with a	ds; show sizes, weights, and lengths of proposed casings; indicate mudding jobs, cements, and all other important proposed work) 18 well in the following manner:
Move in workover rig. Pul	is well in the following manner: 11 tubing. 5075'. Run McCullough Magnetic Survey. 900020. Casing should be made to hold 2000 pai. In cut open hole.
Move in workover rig. Pull Set bridge plug at about 5 Locate casing leaks and so Drill bridge plug and cless Run 4 1/2" OD laner. Ferforate and fracture Man	11 tubing. 5075'. Run McCullough Magnetic Survey. 12 tubing. 13 tubing. 14 tubing. 15 Tubing. 16 Tubing. 16 Tubing. 17 Tubing. 18 Verde formation. 18 Verde formation. 18 Verde formation. 19 SEP 27 1961 OIL CON 19
Move in workover rig. Put Set bridge plug at about a Locate casing leaks and a Drill bridge plug and clear Run 4 1/2" OD laner. Ferforate and fracture Mas Clean out and run tubing.	11 tubing. 5075'. Run McCullough Magnetic Survey. 12 tubing. 13 tubing. 14 tubing. 15 Tubing. 16 Tubing. 16 Tubing. 17 Tubing. 18 Verde formation. 18 Verde formation. 18 Verde formation. 19 SEP 27 1961 OIL CON 19
Move in workover rig. Pulset bridge plug at about a Locate casing leaks and so Drill bridge plug and clear Run 4 1/2" OD liner. Ferforate and fracture Mes Clean out and run tubing.	11 tubing. 5075'. Run McCullough Magnetic Survey. 12 tubing. 13 tubing. 14 tubing. 15 Tubing. 16 Tubing. 16 Tubing. 17 Tubing. 18 Verde formation. 18 Verde formation. 18 Verde formation. 19 SEP 27 1961 OIL CON 19