

Florance L 4

1. Contact Federal or State agency prior to starting repair work.
2. Install and/or test anchors.
3. MIRUSU. Check and record tubing, casing and bradenhead pressures.
4. TOOH with 2 7/8" tubing.
5. Clean out to TD of 2889'.
6. Recavitate as necessary.
7. TIH with 4 1/2" tubing, land tubing at 2684'.
8. Tie well back into surface equipment and turn over to production.

If problems are encountered, please contact:

Robert DeHerrera

(W) (303) 830-4946

(H) (303) 424-4750