

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input type="checkbox"/> Federal Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Walker Com
3. Address of Operator Box 990, Farmington, New Mexico	9. Well No. 2 (OWWO)
4. Location of Well UNIT LETTER K , 1650 FEET FROM THE South LINE AND 1639 FEET FROM THE West LINE, SECTION 32 , TOWNSHIP 31N , RANGE 9W NMPM.	10. Field and Pool, or Wildcat Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.) 6348' GL	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER Workover and Recomplete <input checked="" type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To increase production it is intended to workover and recomplete this well in the following manner:

Due to an 8' piece of iron cement retainer in the bottom of the hole, squeeze cement the open hole through a retainer set near the bottom of the 7" casing with approximately 250 sacks of cement.

Block squeeze cement the 7" annulus at approximately 2700'.

Sidetrack and redrill a new hole through the Mesa Verde formation to approximately 5540'.

Run a full string of 4 1/2" production casing and run cement to tie into the bottom of the 7" casing.

Perforate and sand-water fracture the Mesa Verde formation.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
Carl E. Matthews

SIGNED TITLE **Petroleum Engineer**

DATE

APPROVED BY **Emmy C. Arnold**
CONDITIONS OF APPROVAL, IF ANY:

TITLE

Sup. Dist III

DATE

4-25-66

