

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

SEP 16 1991

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

Bureau of Land Management
Durango, Colorado

5. Lease Designation and Serial No.

14-20-151-46

6. If Indian, Allottee or Tribe Name

Ute Mountain Indian

7. If Unit or CA, Agreement Designation

Ute Indian A

8. Well Name and No.

4

9. API Well No.

30458700300S1

10. Field and Pool, or Exploratory Area

Verde Gallup

11. County or Parish, State

San Juan Co, N.M.

SUBMIT IN TRIPLICATE

1. Type of Well ☐ Oil Well ☒ Gas Well ☐ Other Telephone: 505-325-6771 or 505-327-7634
2. Name of Operator
W.M. Gallaway
3. Address and Telephone No.
3005 Northridge, Suite I, Farmington, N.M. 87401
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
Sec.15, T31N, R15W
1980' FNL, 1980' FEL

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other Work done July 13,15,16 1991

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rolled hole with 9.2# mud 45 viscosity
2. Spotted 30 sks 15# cement across perforation in 5-1/2" casing from PBTD to 1982' and continued up 5-1/2" csg to 1850' Let plug set 4 hours and tagged at 1870'
3. Spotted 20 sks plug of 15# cement from 1585' to 1685'
4. Perforated casing at 640' and squeezed perforations with 30 sks 15# cement inside and outside from 590' to 690'
5. Perforate casing at 158' and circulated with 20 sks cement. Good return throughout.
6. Set 10 sks 15# cement in top 50' of casing
7. Clean location and erect dry hole marker
8. Surface restoration will be handled as specified by surface management agency.

14. I hereby certify that the foregoing is true and correct

Signed

W.M. Gallaway

Title

Operator

Date

8-01-91

(This space for Federal or State office use)

Approved by

(s) Kent Hoffman

Title

ACTING AREA MANAGER

Date

July 16 1991

Conditions of approval, if any: