

EALUM GAS COM 1

PROCEDURES CONTINUED:

10. Set packer @ 2409'.
11. Pmp 10 BFW @ est. injection rate of 4 BPM @ 700 #. REL pkr. x TOH.
12. Set cmt retainer @ 2407'.
13. Pmp 300 sx class B neat cmt, Good circ up annulus AIR 3.5, SIP 700, 63 BBLS slurry).
14. Sting out of retainer x spot 2 BBLS cmt on top of ret.
15. Tag cmt top @ 1730'.
16. Pmp 175 sx class B neat cmt. from 1730'-850'.
17. Pmp 615 sx class B neat cmt and circ. cmt thru Bradenhead.
(Good cmt at surface).
18. Tag cmt top @ 620' and pmp 125 sx class B neat cmt from 620' - surface.
19. Top off csg w/ 2 BBLS cmt.
20. Reclaim Location.

If you have any questions please contact Cindy Burton @ 830-5119.