

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Federal <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name San Juan 32-9 Unit
2. Name of Operator El Paso Natural Gas Company		8. Farm or Lease Name San Juan 32-9 Unit
3. Address of Operator PO Box 990, Farmington, New Mexico 87401		9. Well No. 52 (P&A)
4. Location of Well UNIT LETTER <u>M</u> <u>790</u> FEET FROM THE <u>South</u> LINE AND <u>790</u> FEET FROM THE <u>West</u> LINE, SECTION <u>13</u> TOWNSHIP <u>32N</u> RANGE <u>9W</u> NMPM.		10. Field and Pool, or Wildcat Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.) 6777'GL		12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is planned to plug and abandon this temporarily abandoned well in the following manner:

Perforate the 7 5/8" casing at 2265' (base of Ojo Alamo). Spot an 80 sack cement plug inside the 7 5/8" casing at 2265' and pressure displace approximately 30 sacks through the perforations to cover the Ojo Alamo outside the casing and leave approximately 50 sacks to cover the Ojo Alamo inside the casing.

Shoot the 7 5/8" casing off at the free point and pull the casing. Spot a 50 sack cement plug on the casing stub.

Spot a 25 sack cement plug at the base of the surface casing.

Spot a 15 sack cement plug at the surface with a Plug & Abandon marker. location.

Temporary Abandonment: Completed on May 17, 1963 in the following manner:
Spotted 100 sacks cement plug at 6154' with top of cement at approximately 4606' to cover the perforations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed F. H. WOOD

Petroleum Engineer

October 13, 1971

SIGNED _____ TITLE _____ DATE _____

APPROVED BY Emory Clark TITLE Sup. Pet. Eng. DATE 10-18-71

CONDITIONS OF APPROVAL, IF ANY:

