

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF 079329

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

San Juan 32-9 Unit

8. FARM OR LEASE NAME

San Juan 32-9 Unit

9. WELL NO.

52 (P&amp;A)

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREASec. 13, T-32-N, R-9-W  
NMPM

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

El Paso Natural Gas Company

3. ADDRESS OF OPERATOR

PO Box 990, Farmington, NM 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)

At surface

790'S, 790'W

OCT 18 1971

U. S. GEOLOGICAL SURVEY

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6777'GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON\*

SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL

CHANGE PLANS

(Other)

(Other)

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is planned to plug and abandon this temporarily abandoned well in the following manner:

Perforate the 7 5/8" casing at 2265' (base of Ojo Alamo). Spot a 80 sack cement plug inside the 7 5/8" casing at 2265' and pressure displace approximately 30 sacks through the perforations to cover the Ojo Alamo outside the casing and leave approximately 50 sacks to cover the Ojo Alamo inside the casing.

Shoot the 7 5/8" casing off at the free point and pull the casing. Spot a 50 sack cement plug on the casing stub.

Spot a 25 sack cement plug at the base of the surface casing.

Spot a 15 sack cement plug at the surface with a Plug & Abandon marker at location.

Temporary Abandonment: Completed on May 17, 1963 in the following manner:  
Spotted 100 sack cement plug at 6154' with top of cement at approximately 4606' to cover the perforations.

18. I hereby certify that the foregoing is true and correct

SIGNED Original Signed F. H. WOODTITLE Petroleum EngineerDATE October 13, 1971

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

