

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>OG 794-4</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator <b>Lloyd B. Taylor</b>		8. Farm or Lease Name <b>(Frankel) the Wadsworth</b>
3. Address of Operator <b>407 N. Allen Ave., Farmington, New Mexico 87401</b>		9. Well No. <b>6-1</b>
4. Location of Well UNIT LETTER _____, <b>1650</b> FEET FROM THE <b>North</b> LINE AND <b>1170</b> FEET FROM THE <b>East</b> LINE, SECTION <b>16</b> TOWNSHIP <b>31N</b> RANGE <b>13W</b> NMPM.		10. Field and Pool, or Wildcat <b>Basin Dakota</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>5756 3L (KB 5767)</b>		12. County <b>San Juan</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER _____ <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER _____ <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

T.D. 6674.

Plug back 6300 with wire line bridge plug. Cement plug on top with lump bailer. Pump cement thru tubing from 6200 to 5836 to cover perforation, plus 50'. Shoot pipe off at 3768 and pull with cement over stub, 50 ft. in and 50 ft. out. Cement plug below and into surface casing at 206 ft.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <b>Lloyd B. Taylor</b>	TITLE <b>Operator</b>	DATE <b>July 20, 1971</b>
APPROVED BY <b>James C. [Signature]</b>	TITLE <b>Sup Dist III</b>	DATE <b>7.20.71</b>
CONDITIONS OF APPROVAL, IF ANY:		