

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-B1424.
5. LEASE DESIGNATION AND SERIAL NO.

Use Mtn. 14-20-131-43

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	
2. NAME OF OPERATOR El Paso Natural Gas Products Company	
3. ADDRESS OF OPERATOR Post Office Box 1560, Farmington, New Mexico 87401	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990°/N & 2260°/W, NE/4 NW/4, Section 12, T31N, R15W, NMPM	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5880' DF

6. IF INDIAN, ALLOTTEE OR TRIBE NAME Use Mountain Tribal	
7. UNIT AGREEMENT NAME	
8. FARM OR LEASE NAME Use	
9. WELL NO. 13	
10. FIELD AND POOL, OR WILDCAT Verde Valley	
11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA 31N Sec. 12, T31N, R15W, NMPM	
12. COUNTY OR PARISH San Juan	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was plugged and abandoned on September 6, 1963 in the following manner:

1. Set 130' Cement Plug 1910'-2040'.
2. Cut 5-1/2" OD Casing at 1110' and pulled 1101'.
3. Set 130' Cement Plug 1050'-1160'.
4. Set 100' Cement Plug 260'-260'
(Across top of Point Lookout Formation, Top at 310').
5. Set 30' Cement Plug across bottom of Surface Casing.
6. Set 5 Sack Cement Plug at Surface with 4" Marker.

RECEIVED

DEC 3 1963

U. S. GEOLOGICAL SURVEY
DENVER, COLO.



18. I hereby certify that the foregoing is true and correct

SIGNED BY: **JOHN J. STROJEK** TITLE **Petroleum Engineer** DATE **Dec. 3, 1963**

(This space for Federal or State office use)

APPROVED

CONDITIONS OF APPROVAL IF ANY:

FEB 25 1965

JERRY W. LONG
DISTRICT ENGINEER

TITLE DATE

*See Instructions on Reverse Side

20

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229

