submitted in lieu of Form 3160-5

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT 7 APR 25 Pil 1: 54 Sundry Notices and Reports on Wells 070 FACT ENGROUND ANA

					A 44 0 11 - 11 5 7 7 7 1		
					<u>U FAM</u>	Ľease Ni	umber
					_	14-20-6	
 Type of 	f Well		(News, proper		6.	If Indian,	
Oil			ไกโปร	igeive	16)	Tribe Na	me
				OEIVE		Navajo	
				14V 4 4007	[<i>M</i>] 7.	Unit Agre	ement Name
. Name o	of Operator		F	ar - 1 1897	Same of Same	N/A	
	entury Investment Corp).					
	,		(A)	LCON. DI	TW 8.	Well Nan	ne & Number
Addres	s & Phone No. of Opera	ator		COURT O	j Wo	Navajo	
	alsh Engineering & Pro		505-327	-4892 · 3	9.	API Well	
	•	•	303-321	-4032	Э.		
	East Main, Farmington			 	40		2147800
Locatio	n of Well, Footage, Sec	C., I, K, M			10.	Field and	
							any Rocks
990' F	SL and 1650' FWL Se	c. 17 , T-32-N,	R-17-W, N	NMPM	11.	•	
	\sim					San Jua	in County, NM
, .	Submission Notice of Intent Subsequent Report	_X_ Abando Recom Pluggir	pletion	X Change		g	
l. Describ	Final Abandonment	Casing Altering Other- ted Operations	Repair g Casing	Water S	hut off	1	
		Altering Other - ted Operations	Repair g Casing	Water S Convers	thut off ion to Injection		llows:
21 ^{et}	e Proposed or Complet	Altering Other - ted Operations	Repair g Casing	Water S Convers	thut off ion to Injection		llows:
21* ^t 1.	e Proposed or Complet Century Investment Co Move on and rig up.	Altering Other - ted Operations orp., proposes t	Repair g Casing - to change	Water S Convers P&A procedure	thut off ion to Injection	2/96 as fo	llows:
21* ¹ 1. 2.	ne Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to	Altering Other - ted Operations orp., proposes t	Repair g Casing - to change	Water S Convers P&A procedure	thut off ion to Injection	2/96 as fo	llows:
21* ^t 1. 2. 3.	The Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of	Altering Other - ted Operations orp., proposes to determine free on 7" casing.	Repair g Casing to change	Water S Convers P&A procedure a	thut off ion to Injection	2/96 as fo	llows:
21 ^{et} 1. 2. 3. 4.	ce Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstrice.	Altering Other - ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or as	Repair g Casing to change point. Shows deep as p	Water S Convers P&A procedure and off 4-1/2" casin	thut officion to Injection approved 12/1	2/96 as fol D casing.	
21 ^{et} 1. 2. 3. 4.	The Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of	Altering Other - ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or as	Repair g Casing to change point. Shows deep as p	Water S Convers P&A procedure and off 4-1/2" casin	thut officion to Injection approved 12/1	2/96 as fol D casing.	
21 ^{et} 1. 2. 3. 4. 5.	ce Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstrice.	Altering Other - ted Operations orp., proposes to determine free gon 7" casing. ng to 1697' or as cement to fill Ga	Repair g Casing to change point. Shows deep as p	Water S Convers P&A procedure and off 4-1/2" casin	thut officion to Injection approved 12/1	2/96 as fol D casing.	
21** 1. 2. 3. 4. 5.	e Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstricely #1 - spot sufficient POH and WOC. RIH ar	Altering Other - ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or accement to fill Gand tag cement.	Repair g Casing to change point. Shows deep as pallup perfs	P&A procedure and cover Gallup	thut off ion to Injection approved 12/1 appr	2/96 as fol D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7.	De Proposed or Complete Century Investment Complete Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstrictly plug #1 - spot sufficient POH and WOC. RIH ar Plug #2 - spot approxim	Altering Other - ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or accement to fill Gand tag cement.	Repair g Casing to change point. Shows deep as pallup perfs	P&A procedure and cover Gallup	thut off ion to Injection approved 12/1 appr	2/96 as fol D casing. Dove casing	
21*1 1. 2. 3. 4. 5. 6. 7. hole	Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead or RIH with tubing workstrictly 1- spot sufficient POH and WOC. RIH ar Plug #2 - spot approxime and 7" surface casing.	Altering Other - ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or accement to fill Game of tag cement. ately 65 sxs Clarent	Repair g Casing to change point. Shows deep as pallup perfs ass B ceme	P&A procedure and cover Gallup	thut off ion to Injection approved 12/1 appr	2/96 as fol D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7. hole	Century Investment Co Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstriction POH and WOC. RIH ar Plug #1 - spot approxime and 7" surface casing. POH with tubing; ND BO	Altering Other- ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or accement to fill Gand tag cement. ately 65 sxs Cla	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8	P&A procedure and cover Gallup	thut offion to Injection approved 12/1 ng, POH and L top and 50' al	2/96 as fol D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7. hole	Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead or RIH with tubing workstrictly 1- spot sufficient POH and WOC. RIH ar Plug #2 - spot approxime and 7" surface casing.	Altering Other- ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or accement to fill Gand tag cement. ately 65 sxs Cla	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8	P&A procedure and cover Gallup	thut offion to Injection approved 12/1 ng, POH and L top and 50' al	2/96 as fol D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7. hole 8.	Century Investment Co Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstriction POH and WOC. RIH ar Plug #1 - spot approxime and 7" surface casing. POH with tubing; ND BO	Altering Other- ted Operations orp., proposes to determine free on 7" casing. ng to 1697' or accement to fill Gand tag cement. ately 65 sxs Cla	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8	P&A procedure and cover Gallup	thut offion to Injection approved 12/1 ng, POH and L top and 50' al	2/96 as fol D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7. hole 8. 9.	Century Investment Co Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstricent Plug #1 - spot sufficient POH and WOC. RIH ar Plug #2 - spot approxime and 7" surface casing. POH with tubing; ND BO RD rig and equipment; re-	Altering Other - ted Operations orp., proposes to determine free on 7" casing. In determine fill Gand tag cement. In ately 65 sxs Classing. In the compose of the case of th	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8 n.	P&A procedure and cover Gallup	thut offion to Injection approved 12/1 ng, POH and L top and 50' al	2/96 as fol D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7. hole 8. 9.	Century Investment Co Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstricent Plug #1 - spot sufficient POH and WOC. RIH ar Plug #2 - spot approxime and 7" surface casing. POH with tubing; ND BO RD rig and equipment; re-	Altering Other - ted Operations orp., proposes to determine free on 7" casing. of 1697' or an ement to fill Good tag cement. ately 65 sxs Class CP and wellhead move off location of the compose of the cattern of the	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8 n. correct.	P&A procedure and cover Gallup	thut off ion to Injection approved 12/1 approved 12/1 approved 12/1 approved 12/1 approved 12/1 approved 150° all urface in 6-1/4°	D casing. Dove casing	stub.
21** 1. 2. 3. 4. 5. 6. 7. hole 8. 9.	Century Investment Co Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstricent Plug #1 - spot sufficient POH and WOC. RIH ar Plug #2 - spot approxime and 7" surface casing. POH with tubing; ND BO RD rig and equipment; re-	Altering Other - ted Operations orp., proposes to determine free on 7" casing. of 1697' or an ement to fill Good tag cement. ately 65 sxs Class CP and wellhead move off location of the compose of the cattern of the	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8 n. correct.	P&A procedure and cover Gallup of from 300' to such A marker.	thut off ion to Injection approved 12/1 approved 12/1 approved 12/1 approved 12/1 approved 12/1 approved 150° all urface in 6-1/4°	D casing. Dove casing	
21** 1. 2. 3. 4. 5. 6. 7. hole 8. 9. 4. I hereby	Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstrictly plug #1 - spot sufficient POH and WOC. RIH are Plug #2 - spot approxime and 7" surface casing. POH with tubing; ND BORD rig and equipment; respectively certify that the foregoin C. Thompson	Altering Other - Oth	Repair g Casing to change point. Show s deep as pallup perfs ass B ceme d; install P8 n. correct.	P&A procedure and cover Gallup of from 300' to such A marker.	thut off ion to Injection approved 12/1 approved 12/1 approved 12/1 approved 12/1 approved 12/1 approved 150° all urface in 6-1/4°	D casing. Dove casing	stub.
21* 1. 2. 3. 4. 5. 6. 7. hole 8. 9. 4. I hereby gned Joh	Move on and rig up. Stretch 4-1/2" casing to NU BOP and wellhead of RIH with tubing workstrice Plug #1 - spot sufficient POH and WOC. RIH are Plug #2 - spot approxime and 7" surface casing. POH with tubing; ND BORD rig and equipment; respectively certify that the foregoing and the property of the prop	Altering Other - ted Operations orp., proposes to determine free on 7" casing. In the determine free on 6 or a cement to fill Good tag cement. In ately 65 sxs Clater of the determine of the d	to change point. Shows deep as pallup perfs ass B cemed; install P8 n.	P&A procedure and cover Gallup of from 300' to such A marker.	thut off ion to Injection approved 12/1 appr	D casing. Dove casing	stub.