

Division Approved Plugging Program

Gibson Oil Corp.
John Bergin #2 F-21-29N-11W

Downhole Equipment
Hole of unknown diameter, drilled
to 660'. Uncased.

BEFORE EXAMINER SIGNATURE	
OIL CONSERVATION DIVISION	
OCD	EXAMINER NO. 1
CASE NO. 8862	

1. Clean out hole to TD 660'
2. Set a cement plug 660' - 500'
3. Wait on cement a minimum of 4 hours.
4. Go in hole with tubing and tag plug. If plug is in place, go to step 5. If not, fill to 500'.
5. Set a cement plug 150' to surface.
6. Erect dry hole marker.
7. Fill pits, clean and level location.

All plugs will be with neat cement with or without CaCl_2

F STATE <u>NEW MEXICO</u>	
COUNTY <u>San Juan</u>	SEC. <u>21</u> T. <u>29N</u> R. <u>11W</u>
FIELD OR AREA _____	LOCATION <u>2440' / N 1520' / W</u>
LEASE <u>John Bergin</u>	WELL NO. <u>2</u>
COMPANY <u>Gibson Oil Corp.</u>	SPD. <u>5-13-25</u> COMPLETED <u>6-5-25</u>
ELEV. <u>6135'</u>	T.D. <u>660'</u> P.B. _____
CASING _____	_____
SHOT OR ACID _____	_____
PERF. _____	_____
I.P. _____	_____
PRODUCING FORM _____	_____
PRODUCTIVE DEPTH OR INTERVAL _____	_____

P&A

REMARKS: