



STATE OF NEW MEXICO  
**ENERGY AND MINERALS DEPARTMENT**  
 OIL CONSERVATION DIVISION  
 AZTEC DISTRICT OFFICE

BRUCE KING  
 GOVERNOR

LARRY KEHOE  
 SECRETARY

983-7909

1000 RIO BRAZOS ROAD  
 AZTEC, NEW MEXICO 87410  
 (505) 334-6178

DIVISION APPROVED PLUGGING PROGRAM

*well file*

Smith & Miley  
 Bishop #3  
 A-22-29N-11W

Downhole Equipment - 10" at 115'  
 Hole Size Unknown  
 Total Depth 699'

- 8" 1. Clean out hole to 540'.
2. Set a cement plug 540' - 599'. 440' 35 sks
3. Come out of hole to 400'.
- 8" 4. Set a cement plug 400' - 250'. 53 sks
5. Come out of hole. Watch fluid level for one hour. If fluid level does not drop significantly, go to step #6. If fluid level drops 30' or more wait five more hours and tag plug. If plug is below 300' fill to 250'.
6. Come out of hole to 160'
7. Set a cement plug 160' - 50'. 47 sks
8. Set a top plug and marker with ten sacks of cement. 25'
9. Fill pits, clean and level location.

1.10 cu ft / sk

8" 2.0645  $\frac{ft}{cu ft}$

~~1.10 cu ft / sk~~

10" 2.0820 25'

TD 540'