PHA REPORT WAS RECEIVED IN This
OFFICE & APPARENTLY LOST. PHA
WAS WITNESSED BY + APPROVED BY
C. Gholson In the SAME MANNER AS
The PLUGGING PROGRAM Shows.

## TENTATIVE CEMENTING PROGRAMS

Bloomfield Oil & Gas Co. Sheetz #1 M-14-29N-11W

Division-approved Plugging Program

Clean out hole to 700'

Set a cement plug 700-600' with 15 sacks of neat cement.

Set a cement plug 150'-50' with 30 sacks of neat cement.

Set a top plug with 10 sacks of neat cement. Leave top of cement at

least 3' below ground level, as well is in a cultivated field.

Fill pits, clean & level lovation.

A dry hole marker will not be required.

All plugs will be a Glass A,B or 6 cement with or without Cacl2