

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Southland Royalty Company	8. Farm or Lease Name Hart
3. Address of Operator P.O. Drawer 570, Farmington, NM 87499	9. Well No. #1
4. Location of Well UNIT LETTER <u>L</u> <u>1620</u> FEET FROM THE <u>South</u> LINE AND <u>300</u> FEET FROM THE <u>West</u> LINE, SECTION <u>11</u> TOWNSHIP <u>29N</u> RANGE <u>12W</u> NMPM.	10. Field and Pool, or Wildcat Fulcher Kutz PC
15. Elevation (Show whether DF, RT, GR, etc.)	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 11-5-82 Rig up & pull 1" tubing.
- 11-8-82 Run tubing and spot 10 sacks cement plug across perfs at 1696'-1724'. Pull tubing. Perforate Ojo Alamo at 600' with four squeeze holes at 600'. Run tubing and squeeze with 50 sacks cement. Spot five sacks cement plug from 600' to 500' in 3-1/2" casing. Pull tubing. Bradenhead squeeze with 50 sacks cement.
- 11-9-82 Cut off casing 4' below surface, spot 10 sacks plug at surface, and install dry hole marker.
- 11-12-82 Cleaned location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Petroleum Engineer DATE November 16, 1982

Original [Signature]

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: