

E. C. Brawley

Goodrum #1

0-34-30N-11W

Presumed Downhole Equipment

8" casing at 629'

6" casing at 883'

Total depth 1400'

Plugged Back to 1387'

6" casing may or may not have been pulled

Division-approved Plugging Program

1. Drill out top plug
2. Clean or Drill out hole to 1387'
3. Set a cement plug 1387'-1200'
4. Set a cement plug 700'-600'
5. Set a cement plug 150'-50'
6. Set a top plug, <sup>when in place</sup> and erect marker
7. Fill and level pit and clean location if applicable

All Plugs will be Class A, or C cement with or without CaCl<sub>2</sub>

This hole may have some downhole plugs, blowout prevention equipment should be used.

17. 10. 1968

1. *Journal of the American Medical Association*, 1997; 277: 1001-1005.

1. *Chlorophyll a* and *Chlorophyll b* were determined by the method of Arar and Collins (1971).