## PECOS DISTRICT DRILLING CONDITIONS OF APPROVAL HOBBS OCD

WELL NAME & NO.: SURFACE HOLE FOOTAGE: BOTTOM HOLE FOOTAGE LOCATION:	NM0392082A Hallertau 5 Federal – 16H 490'/S & 378'/W	JUL 0 3 2017 RECEIVED
---	--	--------------------------

Potash	None		⊂ R-111-P
Cave/Karst Potential	C Low	← Medium	High
Variance	None None	Flex Hose	€ Other
Wellhead	Conventional	Multibowl	
Other	□4 String Area	Capitan Reef	□WIPP

## A. Hydrogen Sulfide

1. A Hydrogen Sulfide (H2S) Drilling Plan shall be activated 500 feet prior to drilling into the **Delaware** formation. As a result, the Hydrogen Sulfide area must meet Onshore Order 6 requirements, which includes equipment and personnel/public protection items. If Hydrogen Sulfide is encountered, please provide measured values and formations to the BLM.

## **B.** CASING

- 1. The <u>13-3/8</u> inch surface casing shall be set at approximately 1069 feet (a minimum of 25 feet into the Rustler Anhydrite and above the salt) and cemented to the surface.
  - a. If cement does not circulate to the surface, the appropriate BLM office shall be notified and a temperature survey utilizing an electronic type temperature survey with surface log readout will be used or a cement bond log shall be run to verify the top of the cement. Temperature survey will be run a minimum of six hours after pumping cement and ideally between 8-10 hours after completing the cement job.
  - b. Wait on cement (WOC) time for a primary cement job will be a minimum of <u>8</u> <u>hours</u> or 500 pounds compressive strength, whichever is greater. (This is to include the lead cement)
  - c. Wait on cement (WOC) time for a remedial job will be a minimum of 4 hours after bringing cement to surface or 500 pounds compressive strength, whichever is greater.
  - d. If cement falls back, remedial cementing will be done prior to drilling out that string.
- 2. The minimum required fill of cement behind the 9-5/8 inch intermediate casing is:

- Cement to surface. If cement does not circulate see B.1.a, c-d above.
- In <u>High Cave/Karst Areas</u> if cement does not circulate to surface on the first two casing strings, the cement on the 3rd casing string must come to surface.
- 3. The minimum required fill of cement behind the <u>7</u> inch production casing is:
  - Cement should tie-back at least 200 feet into previous casing string. Operator shall provide method of verification.
- 2. The minimum required fill of cement behind the 4-1/2 inch production liner is:
  - Cement should tie-back at least 200 feet into previous casing string. Operator shall provide method of verification.

## C. PRESSURE CONTROL

.

- 1. Variance approved to use flex line from BOP to choke manifold. Manufacturer's specification to be readily available. No external damage to flex line. Flex line to be installed as straight as possible (no hard bends).'
- 2. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the surface casing shoe shall be 2000 (2M) psi.
- 3. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the 9-5/8" intermediate casing shoe shall be 5000 (5M) psi.
- Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the 7" intermediate casing shoe shall be 10,000 (10M) psi. (Note: The attached drilling plan states a 5M is required for drilling 6 inch hole but the AFMSS 2 data reflects 10M – 10M is correct.)

CRW 6/12/2017