

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION C.

APR 29 11 05 AM '69

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Major, Giebel & Forster		8. Farm or Lease Name Meta Schmidt
3. Address of Operator 1126 Vaughn Building, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>P</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>710</u> FEET FROM THE <u>East</u> LINE, SECTION <u>3</u> TOWNSHIP <u>9-S</u> RANGE <u>34-E</u> NMPM.		10. Field and Pool, or Wildcat Jenkins Penn
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set cast iron plug at 9500' with 20' cement on top. Shot casing at 7994' Cut 5 1/2" casing at 6491'. Spotted 25 sx cement.

Set 25 sx cement at 5300', 25 sx at bottom of casing, 3987'.

Cut 8 5/8" casing off at 1275'. Set 25 sx cement at 1275', 25 sx cement at 385' and 10 sx at surface. Installed dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>A. T. Giebel</u>	TITLE <u>Partner</u>	DATE <u>4/24/69</u>
APPROVED BY <u>John W. Runyan</u>	TITLE <u>Manager</u>	DATE <u>4/24/69</u>
CONDITIONS OF APPROVAL, IF ANY:		