

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
**L -6456**

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name -
2. Name of Operator <b>ARNO R. DALBY C/o W. W. Ranck</b>	8. Farm or Lease Name <b>BASS - STATE</b>
3. Address of Operator <b>1603 Broadway, Lubbock, Texas 79401</b>	9. Well No. <b>#1</b>
4. Location of Well UNIT LETTER <b>F</b> <b>1980</b> FEET FROM THE <b>W</b> LINE AND <b>1650</b> FEET FROM THE <b>N</b> LINE, SECTION <b>16</b> TOWNSHIP <b>7 - S</b> RANGE <b>32 - E</b> NMPM.	10. Field and Pool, or Wildcat <b>NW TODD (SA)</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4252 GR</b>	12. County <b>ROOSEVELT</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Placed bridge plug at 4050', put 200' cement on top of plug.
- Shot casing at 1438'
- Loaded hole with mud laden fluid.
- Put 100' cement plug on top of shot off pipe.
- Put 100' plug at base of surface casing.
- Put 10 sacks of cement at surface with maker.

3/12/75

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *W. W. Ranck* TITLE W. W. Ranck, Agent DATE 3/20/75

APPROVED BY *John W. Runyon* TITLE Geologist DATE FEB 22 1977

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAY 1 1970

C. L. CONSERVATION COMM.  
HOBBS, N. M.