

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8176	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name	
2. Name of Operator Cabot Petroleum Corporation.		8. Farm or Lease Name New Mexico 'C' State	
3. Address of Operator P. O. Box 5001, Pampa, TX 79065		9. Well No. 2	
4. Location of Well UNIT LETTER <u>D</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>440</u> FEET FROM THE <u>West</u> LINE, SECTION <u>36</u> TOWNSHIP <u>13S</u> RANGE <u>37E</u> N.M.P.M.		10. Field and Pool, or Wildcat King Wolfcamp	
15. Elevation (Show whether DF, RT, GR, etc.) 3844' GR		12. County Lea	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Upon Commission approval, plan to:

1. Rig up and drill out retainer @ 9500'.
2. Perforate Lower Wolfcamp from 9810'-9960'.
3. Acidize perforations 9810'-9960'.
4. Swab test new perforations.
5. Acidize 9232'-9392' (Existing perfs.)
6. Place well on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED G. Miller Farmer TITLE Agent DATE 5/21/85

ORIGINAL SIGNED BY GERRY SEXTON
DISTRICT 1 SUPERVISOR

MAY 23 1985

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAY 22 1985

O.C.D.
HOBES OFFICE