

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
K-191

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator The Superior Oil Company	8. Farm or Lease Name State "F"
3. Address of Operator P. O. Box 1900, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>2130</u> FEET FROM THE <u>East</u> LINE, SECTION <u>5</u> TOWNSHIP <u>13-S</u> RANGE <u>36-E</u> N.M.P.M.	10. Field and Pool, or Wildcat Tatum (Wolfcamp)
15. Elevation (Show whether DF, RT, GR, etc.) 4016 KB, 4001 GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Workover to isolate Wolfcamp perforations 10,362-10,366 and perforate higher in the Wolfcamp 10,090-10,097.

1. Set cast iron bridge plug at 10,300 and dump 1 sack cement on top.
2. Perforate Wolfcamp 10,090-10,097.
3. Swab test and stimulate for production as necessary.

Starting date: April 5, 1968

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED O. V. Sivage O. V. Sivage TITLE Production Engineer DATE April 4, 1968

APPROVED BY [Signature] TITLE SUPERVISOR DATE 4/6

CONDITIONS OF APPROVAL, IF ANY: