

RECOMMENDED WORK PROCEDURE cont.

p. 2

17. TAG CMT PLUG TOP @ 380'. RE-SPOT PLUG IF NECESSARY.

18. SPOT 10 SK CMT PLUG @ SURFACE.

19. ERECT P&A MARKER.

20. RDMO PULLING UNIT.

21. CLEAN & CLEAR LOCATION.

NOTE: WHEN SPOTTING ALL PLUGS, BE SURE THAT 9.5 LB/GAL MUD IS
BETWEEN THE PLUGS.

VERBAL APPROVAL ON PROCEDURE BY PAUL KAUTZ - NMOCD HOBBS 5-12-87

KA CARWILE

Tril for KBL 5-15-87