

LC 059002

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1.  OIL WELL  GAS WELL  OTHER Injection Well

2. NAME OF OPERATOR  
Continental Oil Company

3. ADDRESS OF OPERATOR  
P. O. Box 460, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\* See also space 17 below.)  
At surface  
1980' FNL and 660' FWL of Sec 34

7. UNIT AGREEMENT NAME  
MCA

8. FARM OR LEASE NAME  
MCA Unit #3

9. WELL NO.  
229

10. FIELD AND POOL, OR WILDCAT  
Malj G-SA Repers

11. SECT., B., S., OR BLK. AND SURVEY OR AREA  
Sec 34, T-17S, R-32E

12. COUNTY OR PARISH  
Lea

13. STATE  
N. Mex

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GN, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	<input checked="" type="checkbox"/>	PULL OR ALTER CASING	<input type="checkbox"/>
FRACATURE TREAT	<input type="checkbox"/>	MULTIPLE COMPLETE	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	ABANDON*	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	CHANGE PLANS	<input type="checkbox"/>
(Other)	<u>Deepen 34' - same zone</u>		<input checked="" type="checkbox"/>

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
FRACATURE TREATMENT	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
SHOOTING OR ACIDIZING	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
(Other)			

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is proposed to shut-off water and deepen this well by the following procedures. Spot pea gravel and sand plug from TD back to 4150'. Run 2 3/4" tbg and sand plug. Spot 200 socks cross C cement containing 0.9 gal liquid latex per sock. Pull tbg up to 3200' and squeeze cement away at 500-600 psi. WOC 36 hrs. Go in hole w/ 4 3/4" bit and drill out cmt plug. Drill out to new TD of 4290'. Re-run cmt-lined tbg w/ packer and place back on injection.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Administrative Supervisor DATE 12-28-71

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

USGS (5) File MCA(3)

**APPROVED**  
 DEC 29 1971  
 ARTHUR R. BROWN  
 DISTRICT ENGINEER

\*See Instructions on Reverse Side