

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

HOBBS OFFICE O. G. C.
NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.
E-2929

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Cities Service Oil Company	8. Farm or Lease Name State BM
3. Address of Operator P. O. Box 69 - Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER K , 1980 FEET FROM THE West LINE AND 1980 FEET FROM THE South LINE, SECTION 16 TOWNSHIP 15S RANGE 36E NMPM.	10. Field and Pool, or Wildcat Caudill Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3912 DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

<p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER Plug Back & Recomplete in Hueco Form. <input checked="" type="checkbox"/></p>	<p>SUBSEQUENT REPORT OF:</p> <p>PLUG AND ABANDON <input type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p> <p>REMEDIAL WORK <input type="checkbox"/></p> <p>COMMENCE DRILLING OPNS. <input type="checkbox"/></p> <p>CASING TEST AND CEMENT JOB <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p> <p>ALTERING CASING <input type="checkbox"/></p> <p>PLUG AND ABANDONMENT <input type="checkbox"/></p>
---	--

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to recomplete the State BM #1 in the Hueco formation in the following manner:

- 1. Set BOP with one set of blind rams.**
- 2. Set cast iron bridge plug at 11250' with 2 sacks cement dumped on top.**
- 3. Block squeeze 10567-10180.**
- 4. Drill out cement to 11200'.**
- 5. Perforate with 23 holes from 10225 thru 10517'.**
- 6. Acidize - if necessary - with 4000 gal. 15% acid.**
- 7. Swab test.**

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **Cl. E. Robertson** ORIGINAL SIGNED
TITLE **District Office Manager** DATE **May 12, 1969**

APPROVED BY **Leslie A. Clements** TITLE **Oil & Gas Inspector** DATE **May 12, 1969**

CONDITIONS OF APPROVAL, IF ANY: